



## Nitro Temp Sensor Installation

Covers Part Number(s):  
6521





### Required:

- Temp Sensor 6521


### Tools Needed:

- 2.0mm hex wrench (optional)



### Installation Steps:

1. Wrap temp sensor around the engine head between the cooling fins. (A)
2. Secure temp sensor to engine head with a small piece of fuel tubing. (A)
3. Using a 2.0mm hex wrench (if necessary), remove the receiver box cover (B).
4. Route temp sensor into the receiver box, making sure to secure the wire to the chassis avoiding all moving parts. (C)
5. Plug the grey connector into the V/T slot on the receiver. To also monitor the receiver battery voltage, plug the red connector into any open slot on the receiver. (D)
6. Reinstall receiver box cover.



If you have questions or need technical assistance, call Traxxas at

# 1-888-TRAXXAS

(1-888-872-9927) (U.S. residents only)

TRAXXAS.COM

Traxxas, 1100 Klein Road, Plano, TX 75074, Phone: 972-265-8000, Fax: 972-265-8011, e-mail: support@Traxxas.com